



# **ONE-MAN CHAIR BLIND**

*Instruction Manual*



**TANGLE™**

**Model # 881  
Ameristep® Tangle™**

**Be sure to follow these guidelines for using your Product.  
READ AND UNDERSTAND ALL INSTRUCTIONS and WARNINGS FIRST**  
Any questions or confusion regarding the use of this product contact our  
Customer Service Department at Ameristep® (810) 686-4035 before using.

©2008  
(rev 1/08)

**SAFETY MUST BE FIRST PRIORITY WITH USE OF THIS PRODUCT**



**Step 1:** Remove your Blind from Back Pack.



**Step 2:** Unsnap cinch strap (fig 2 and 3) and open chair (fig 4).



**Step 3:** Grab steel bands from behind chair and pull forward until blind is fully covering chair (shown in figs 5, 6, 7)



**Step 5:** Ground stakes are included with your chair blind to help secure blind to the ground.

**! Tip**

Be sure to remove all native brush, dirt and debris **BEFORE** beginning take down.



**Step 1:** Remove Ground Stakes.



fig 1



fig 2



fig 3

**Step 2:** Once out of blind, lift blind up and over back of chair so that blind cover falls to behind chair (fig 1 and 2).

**Step 3:** Close chair by pulling up on seat and bring legs together (fig 3).



fig 4



fig 5

**Step 4:** Place cinch strap around blind and snap together to keep Chair Blind closed.

**Step 5:** Place Chair Blind into backpack.



**PARTS LIST**

- 1 Ameristep® One-Man Chair Blind (34" Wide x 45" Deep x 54" Tall)
- Model # 881
- 1 Chair (20" Wide x 17" Deep)  
16" High to Seat and 35" High to Seat Back
- 1 Carrying Case
- Tent Stakes

**FEATURES**

- Packed: 15" x 36" Long
- 5 Windows
- Weight: 10.5 lbs.
- Chair Rated For: 250 lbs.

**STORAGE AND TIPS**

- Store your Blind in a cool dry place - free native brush, dirt and any debris
- Never store your Blind wet or damp
- Avoid leaving your Blind outdoors for any extended period of time
- To stop any leakage, use seam sealer on all seams and silicon spray on seams/sidewalls.
- To store your TSC windows and/or Shoot-Through Mesh (if included with your Blind or purchased separately), avoid wrinkles and creases that could significantly reduce visibility
- To aid in folding blind be sure the window curtain is all the way up

⚠ Warning ⚠ Warning ⚠ Warning ⚠

**THINK SAFETY !**

- **NEVER** USE A HEATER IN YOUR AMERISTEP® BLIND - UNVENTED FUMES COULD CAUSE SICKNESS OR DEATH
- **NEVER** EXPOSE YOUR BLIND TO ANY OPEN FLAME. THIS PRODUCT IS NOT FIREPROOF
- **NEVER** SHOOT THROUGH THE TSC WINDOWS WITH A FIREARM SPARKS OR FLAME FROM THE MUZZLE COULD IGNITE THE MATERIAL
- **NEVER** SHOOT EXPANDABLE BROADHEADS THROUGH THE TSC WINDOWS - THE MESH MAY CAUSE PREMATURE OPENING OF THE BLADES. USE FIXED BLADE BROADHEADS ONLY
- FOR BEST ARROW FLIGHT THRU TSC WINDOWS, ALIGN BROADHEAD BLADES WITH FLETCHING
- **NEVER** ALLOW CHILDREN TO PLAY WITH THIS PRODUCT WITHOUT ADULT SUPERVISION
- **NEVER** ALLOW MATERIAL TO COVER YOUR FACE. IT CAN CAUSE SUFFOCATION AND DEATH
- **NEVER** ALLOW ANYONE TO USE LIGHTED CANDLES, MATCHES OR OTHER SOURCES OF FIRE NEAR THIS PRODUCT
- UV (ULTRAVIOLET LIGHT) WARNING:  
Ultraviolet light breaks down lightweight fabric fibers (and almost any synthetic material). The material will fade (discolor), lose strength and eventually disintegrate if left in prolonged sunlight. To extend the life of your Ameristep® product avoid leaving it out in direct sunlight. Set up your portable ground blind or accessory in a shady spot whenever possible to extend the product life.

See our Full Line  
of Products, Accessories and Replacement Parts at:

**AMERISTEP**.com